WIRELESS WHITE BULB

Bulb - assembly and settings / how to do it?

Assembly

Replace your existing bulb with the wireless-controlled bulb.

E27

Remove the existing bulb.

Screw the new wireless bulb.

Settings

Assigning to system units.

address of bulb

B0061S

Each bulb has its own **address** (unique code). You insert this directly into the application **iHC-MAIRF / iHC-MIIRF** or into the touch control unit **RF Touch**.

Assigning to controllers.

the existing push-button

Switch on the push-button three times at an interval of around 1 s (last position on) = programmable mode - the bulb flashes for 5 s while waiting for assignment of the controller.

RF

RF

or

RF **KEY**
~ 1 press

RFWB-40/G
- 1 press

Delete the assigned controller by switching on the existing 5 times (last position on - the bulb will flash 5x).

Control

FUNCTION OF BUTTONS
1) < 0.5 s = ON/OFF
   > 0.5 s = brightness settings
2) > 0.5 s = temperature settings
3), 4) open for adding further units

The last bulb settings are automatically stored after 15 seconds to be controlled by the existing push-button.

iNELS Home Control

The application iNELS Home Control enables dimming of lighting, switching appliances, heating, control of blinds and all devices connected to the RF Control System, including IP video cameras via the Smart RF Box.

▶ Google play

 App Store

iHC-MAIRF

iHC-MIIRF

WE CAN CONTROL
YOUR HOME
VIA SMARTPHONE!

MY HOUSE   OBYV

Smart RF Box

Heating

Cameras

Lighting

Air-conditioning

Blinds

---

iNELS
smart home solutions

Configuring the application / how to do it?

1. Click on **"Configuration"**, then on **"Settings "** and go to the tab **"Units"**.

In this screen, you simply configure the device.

Any name for the device will suffice

Select eLAN

Number of unit listed on the bulb see image 1.
Name of given element see image 2.

Select type of device see image 3.

Select a room

Then confirm by pressing **"Save"**

CONGRATULATIONS!
The device is ready to use!

2. To add further Units, click on **"Add"** and enter the required data (**Name of unit**: any, **Select eLAN**, **Enter an address of actuator**: see image 1, **Type of actuator**: type designation of unit - see image 2, **Select of icon**: according to function of given unit; see image 3, **Please select a room**), By pressing on **"Save"**, insert the unit.

image 1

B0061S

image 2

RF-RGB-LED-550
RF-White-LED-675

image 3

02-53/2016 rev.2